

Product Code

UTA-0600	Los Angeles Abrasion Machine, 220-240 V 50 Hz (60 Hz version is available upon request)
UTA-0600/110	Los Angeles Abrasion Machine, 110 V 60 Hz
UTA-0601	Los Angeles Abrasion Machine with Soundproof Safety Cabinet, 220-240 V 50 Hz (60 Hz version is available upon request)
UTA-0601/110	Los Angeles Abrasion Machine with Soundproof Safety Cabinet, 110 V 60 Hz
UTA-0602/E	Los Angeles Abrasion Charges EN, 12 pcs.
UTA-0602/A	Los Angeles Abrasion Charges ASTM/AASHTO, 12 pcs.

Standards

EN 1097-2, 12697-17, 13450; ASTM C131, C535; AASHTO T96

The Los Angeles Abrasion Machine is used for determination of the aggregates resistance to fragmentation. The machine consists of an electronic control unit and a rolled steel drum having an inside diameter of 711 mm and internal length of 508 mm. The drum is rotated at a speed of 31-33 r.p.m. The internal shelf provided with the machine conforms to ASTM, AASHTO and EN standards. The machine is equipped with an automatic counter, when the preset revolution count is reached, the machine will stop automatically. The drum is equipped with an interlock device which allows the operator to lock the drum into position for easy loading/unloading of the sample.

A steel tray is supplied with the machine for easy discharge of specimen and abrasive charges.

The standard model can be supplied with a safety/noise reduction cabinet. The cabinet is lined internally with soundproofing material to reduce sound level conforming to CE directives. The cabinet must be ordered with the Los Angeles machine if required, as the electronic control unit will be installed on the safety cabinet at the time of manufacture. The cabinet is equipped with an electric safety device which automatically stops the rotation of the drum when the door is opened, conforming to CE directives.

- Abrasion balls and 1.6 mm, 10mm, 11.2mm (or 12.5mm) and 14 mm sieves acc. to EN standard,
 - Abrasion balls, 1.7 mm (No.12) sieve and other sieves which chance depending the grain size acc. to ASTM and AASHTO standards,
- should be ordered separately.

The Los Angeles Abrasion Machine is supplied complete with

- Steel Tray



UTA-0600



Drum Position Lock with Safety Switch



UTA-0601



Control Panel

	UTA-0600	UTA-0601
Dimensions	850x1000x1100 mm	1100x1150x1250 mm
Weight (approx.)	380 kg	505 kg
Power	750 W	750 W